






SIDE MOUNT FILTER



VALVE V1 IS TO BE OPENED
DURING FAST RINSE ONLY



**EXPLODED VIEW FOR SIDE MOUNT FILTER
MULTI-PORT VALVE (40NB)**







40 NB SIDE MOUNT FILTER MULTIPOINT VALVE

SR. NO.	DESCRIPTION	PART NO.
1	HANDLE	A1
2	HANDLE WASHER	A2
3	TOP COVER	A3
4	SPRING WASHER	A4
5	DISC	A5
6	BODY	A6
7	LARGE ELBOW	A8
8	NUT	A9
9	SPLIT WASHER	A10
10	40 NB UNION ADAPTOR	A15
11	PIN (8 mm)	S1
12	NUT, BOLT & WASHER	S2
13	SPRING	S3
14	TOP COVER ' O ' RING (DIA 135X3.5 THK)	N1
15	STAR SHAPED WASHER	N2
16	DISC ' O ' RING (DIA 18X3.5 THK)	N3
17	ELBOW ' O ' RING (DIA 47X3 THK)	N4

**SIDE MOUNT FILTER
MULTI PORT VALVE
GENERAL ASSEMBLY**




SIDE MOUNT SOFTNER





VALVE V1 IS TO BE OPENED
DURING FAST RINSE ONLY

EXPLODED VIEW FOR SIDE MOUNT SOFTNER MULTI-PORT VALVE (40NB)




40 NB SIDE MOUNT SOFTNER MULTIPOINT VALVE

SR. NO.	DESCRIPTION	PART NO.
1	HANDLE	A1
2	HANDLE WASHER	A2
3	TOP COVER	A3
4	SPRING WASHER	A4
5	DISC	A5
6	BODY	A6
7	' U ' PIN	A7
8	LARGE ELBOW	A8
9	NUT	A9
10	SPLIT WASHER	A10
11	SQUARE ADAPTOR	A11
12	' C ' SHAPED EJECTOR	A12
13	HOSE NIPPLE	A13
14	40 NB UNION ADAPTOR	A15
15	PIN (8 mm)	S1
16	NUT, BOLT & WASHER	S2
17	SPRING	S3
18	TOP COVER ' O ' RING (DIA 135X3.5 THK)	N1
19	STAR SHAPED WASHER	N2
20	DISC ' O ' RING (DIA 18X3.5 THK)	N3
21	ELBOW ' O ' RING (DIA 47X3 THK)	N4
22	EJECTOR ' O ' RING (DIA 18X2.5 THK)	N5
23	SQUARE ADAPTOR ' O ' RING (DIA 24X3.5 THK)	N6




**SIDE MOUNT SOFTNER
MULTI PORT VALVE
GENERAL ASSEMBLY**



TOP MOUNT 40 NB VALVE WITH M.S. VESSEL
(4" TOP OPENING ONLY)
FOR UPFLOW SOFTENER/DEMINERALISER


1. MPV WITH L-SHAPED ADAPTER
2. 4" x 4" ADAPTOR
3. TOP HUB & LATERALS
4. 40NB PVC PIPE (50mm)
5. BOTTOM HUB (WITH CAP & LOCK PIN & LATERALS)



TOP MOUNT FILTER


TOP MOUNT 40 NB VALVE FOR FILTERS
: FRP / MS VESSEL

1. TOP MOUNTED FILTER VALVE & L-SHAPED ADAPTOR WITH INLET DISTRIBUTOR.
2. BOTTOM HUB (WITH CAP & LOCK PIN & LATERALS)
3. 40NB PVC PIPE (50mm)




TOP MOUNT 40 NB FOR 2.5" TOP OPENING ONLY
: MS / FRP / HOPE VESSELS
: FILTER / UPFLOW SOFTENER / DEMINERALISER
MAX. FLOW - 6M³ / Hr.

1. TOP MOUNTED VALVE & L-SHAPED ADAPTOR WITH 32 mm SOCKET
2. 4" x 2.5" ADAPTOR
3. TOP DOUBLE STRAINER
4. BOTTOM DOUBLE STRAINER
5. 32 mm PVC PIPE





**EXPLODED VIEW FOR TOP MOUNT FILTER
MULTI-PORT VALVE (40NB)**



40 NB TOP MOUNT FILTER MULTIPOINT VALVE

SR. NO.	DESCRIPTION	PART NO.
1	HANDLE	A1
2	HANDLE WASHER	A2
3	TOP COVER	A3
4	SPRING WASHER	A4
5	DISC	A5
6	BODY	A6
7	NUT	A9
8	SPLIT WASHER	A10
9	40 NB UNION ADAPTOR	A15
10	L - SHAPED ADAPTOR	A16
11	40 NB MTA	A17
12	L - SHAPED ADAPTOR ELBOW	A19
13	PIN (8 mm)	S1
14	NUT, BOLT & WASHER	S2
15	SPRING	S3
16	TOP COVER ' O ' RING (DIA 135X3.5 THK)	N1
17	STAR SHAPED WASHER	N2
18	DISC ' O ' RING (DIA 18X3.5 THK)	N3
19	ELBOW ' O ' RING (DIA 47X3 THK)	N4
20	40 NB MTA ' O ' RING (DIA 50X3 THK)	N8
21	4" ADAPTOR WASHER	N9




**TOP MOUNT FILTER
MULTI PORT VALVE
GENERAL ASSEMBLY**

INLET/OUTLET/DRAIN : 1 1/2" BSPF
EJECTOR SUCTION : 1/2" HOSE NIPPLE
VESSEL TOP : 4" 8 U.N.F.
RISER PIPE : 32mm PVC / 50mm PVC

**TOP MOUNT 40 NB VALVE WITH M.S. VESSEL
(4" TOP OPENING ONLY)
FOR UPFLOW SOFTENER/DEMINERALISER**


1. MPV WITH L-SHAPED ADAPTER
2. 4" x 4" ADAPTOR
3. TOP HUB & LATERALS
4. 40NB PVC PIPE (50mm)
5. BOTTOM HUB (WITH CAP & LOCK PIN & LATERALS)



TOP MOUNT SOFTNER


**TOP MOUNT 40 NB VALVE FOR SOFTNER
: FRP / MS VESSEL**

1. TOP MOUNTED SOFTNER VALVE & L-SHAPED ADAPTOR WITH INLET DISTRIBUTOR.
2. BOTTOM HUB (WITH CAP & LOCK PIN & LATERALS)
3. 40NB PVC PIPE (50mm)




**TOP MOUNT 40 NB FOR 2.5" TOP OPENING ONLY
: MS / FRP / HOPE VESSELS
: FILTER / UPFLOW SOFTENER / DEMINERALISER
MAX. FLOW - 6M³ / Hr.**

1. TOP MOUNTED VALVE & L-SHAPED ADAPTOR WITH 32 mm SOCKET
2. 4" x 2.5" ADAPTOR
3. TOP DOUBLE STRAINER
4. BOTTOM DOUBLE STRAINER
5. 32 mm PVC PIPE





**EXPLODED VIEW FOR TOP MOUNT SOFTNER
MULTI-PORT VALVE (40NB)**



40 NB TOP MOUNT SOFTNER MULTIPOINT VALVE

SR. NO.	DESCRIPTION	PART NO.
1	HANDLE	A1
2	HANDLE WASHER	A2
3	TOP COVER	A3
4	SPRING WASHER	A4
5	DISC	A5
6	BODY	A6
7	' U ' PIN	A7
8	NUT	A9
9	SPLIT WASHER	A10
10	SQUARE ADAPTOR	A11
11	' C ' SHAPED EJECTOR	A12
12	HOSE NIPPLE	A13
13	40 NB UNION ADAPTOR	A15
14	L - SHAPED ADAPTOR	A16
15	40 NB MTA	A17
16	L - SHAPED ADAPTOR ELBOW	A19
17	$\frac{3}{4}$ " MTA	A20
18	PIN (8 mm)	S1
19	NUT, BOLT & WASHER	S2
20	SPRING	S3
21	TOP COVER ' O ' RING (DIA 135X3.5 THK)	N1
22	STAR SHAPED WASHER	N2
23	DISC ' O ' RING (DIA 18X3.5 THK)	N3
24	ELBOW ' O ' RING (DIA 47X3 THK)	N4
25	EJECTOR ' O ' RING (DIA 18X2.5 THK)	N5
26	SQUARE ADAPTOR ' O ' RING (DIA 24X3.5 THK)	N6
27	$\frac{3}{4}$ " MTA ' O ' RING (DIA 30X3 THK)	N7
28	40 NB MTA ' O ' RING (DIA 50X3 THK)	N8
29	4" ADAPTOR WASHER	N9



**TOP MOUNT SOFTNER
MULTI PORT VALVE
GENERAL ASSEMBLY**

INLET/OUTLET/DRAIN : 1 1/2" BSPF
EJECTOR SUCTION : 1/2" HOSE NIPPLE
VESSEL TOP : 4" 8 U.N.F.
RISER PIPE : 32mm PVC / 50mm PVC